

DMX TABELLA FOR SCAN2ALT

CHANNEL	FUNKCION	TYPE OF CONTROL	EFFECT	PERCENT	DECIMAL		
1	PAN (X mirror)	proportional	coarse control of the X movement	0 / 100%	0 - 255		
2	TILT (Y mirror)	proportional	coarse control of the y movement	0 / 100%	0 - 255		
3	GOBO	step	no gobo		0 - 24		
		step	gobo1		25 - 48		
		step	gobo2		49 - 72		
		step	gobo3		73 - 96		
		step	gobo4		97 - 120		
		step	gobo5		121 - 144		
		step	gobo6		145 - 168		
		step	gobo7		169 - 192		
		step	rot1		192 - 203		
		step	rot2		204 - 215		
		step	rot3		216 - 227		
		step	rot4		228 - 239		
		step	rot5		240 - 255		
		4	COLOR	step	color 1 white		0 - 24
				step	color 2 yellow		25 - 48
step	color 3 orange				49 - 72		
step	color 4 red				73 - 96		
step	color 5 cyan				97 - 120		
step	color 6 green				121 - 144		
step	color 7 light blue				145 - 168		
step	color 8 dark blue				169 - 192		
step	rot1				192 - 203		
step	rot2				204 - 215		
step	rot3				216 - 227		
step	rot4				228 - 239		
step	rot5				240 - 255		
5	SHUTTER			step	closed		0 - 64
				step	open		65 - 128
		step	strobe speed 1	1Hz	129 - 142		
		step	strobe speed 2	2Hz	143 - 156		
		step	strobe speed 3	3Hz	157 - 170		
		step	strobe speed 4	4Hz	171 - 184		
		step	strobe speed 5	5Hz	185 - 198		
		step	strobe speed 6	6Hz	199 - 212		
		step	strobe speed 7	7Hz	213 - 226		
		step	strobe speed 8	8Hz	227 - 240		
		step	open		241 - 255		
6	PRIZM ROT	proportional	off		0 - 41		
		proportional	prizm wheel rotate continuously, speed from min to max		42 - 255		
7	GOBO ROT	proportional	hold		0 - 25		
		proportional	gobo wheel rotate continuously, speed from min to max		26 - 127		
		proportional	hold		128 - 152		
		proportional	gobo wheel rotate continuously, speed from max to min		153 - 255		
8	RESET	step	off		0 - 127		
		step	on		128 - 255		
9	LAMP OFF	step	off		0 - 127		
		step	on		128 - 255		
10	SPEED (MIRROR)	proportional	max. speed		0 - 7		
		proportional	continoues		8 - 239		
		proportional	min. speed		240 - 249		
		proportional	max. speed, auto shade mirrors		250 - 255		
11	PAN FINE	proportional	fine control of the X movement	0 / 100%	0 - 255		
12	TILT FINE	proportional	fine control of the Y movement	0 / 100%	0 - 255		
NOTE : dip-swiches (10 PIN) 10 must be ON =							
NOTE : dip-swiches (10 PIN) 9, 10 must be ON =							
NOTE : dip-swiches (10 PIN) 8, 9, 10 must be ON =							
NOTE : dip-swiches (2 PIN) 1 must be ON =							
NOTE : dip-swiches (2 PIN) 2 must be ON =							